



Buy it for looks. Buy it for life.®


Illustrated Parts

■ Order by Part Number

Two-Handle Laundry Faucet		
MODEL	HANDLE	FINISH
4872	Chrome Knob	Chrome
4873	Acrylic Knob	Chrome

Handle Insert Kit


- 103058 HOT
- 103059 COLD



Handle Screw
12648



Spout Assembly
91992



Garden
Hose Adapter
(Obsolete)
92018



Retaining Ring
&
Spout O-Ring
101879




Cartridge Nut
14986




Spout Nut
14939



Replacement Cartridge
1224



Escutcheon
13567



Hardware Package
13678

