

■ Order by Part Number

RINZA™ Single-Handle Lavatory Faucet		
MODEL	FINISH	NOTES
84627	Chrome	Spring-Loaded Waste
84627SRN	Spot Resist Brushed Nickel	Spring-Loaded Waste
84627BL	Matte Black	Spring-Loaded Waste

Set Screw (Requires 3/32" hex key)

159195

Handle Kit

198949 Chrome
198949SRN Spot Resist Brushed Nickel
198949BL Matte Black

Handle Dome

160660 Chrome
160660SRS Spot Resist Brushed Nickel
160660BL Matte Black

Cartridge, Cartridge Nut & Set Screw

160657

Aerator Kit - Includes Tool

183732

Deck Gasket

150567

Deck Plate Kit


172666 Chrome
172666SRN Spot Resist Brushed Nickel
172666BL Matte Black

Mounting Hardware

146190

Installation Tool

118305



WASTE ASSEMBLIES	
For Waste Service Order Full Assembly	
Spring-Loaded Waste - Full Assembly	
186478	Chrome
186478CSL	Classic Stainless (Used for Spot Resist Brushed Nickel)
186478BL	Matte Black

