

## Illustrated Parts

### Order by Part Number

Stopper - Polished Stainless

1011




Removable Splash Guard

205497



Sink Flange - Polished Stainless

1017



### Mounting Assembly Kit - 1824

Fiber Gasket



Backup Flange



Screws (x3)



Mounting Ring



Snap Ring



Cushion Mount



Lower Mounting Ring




### Drain Elbow Kit - 1026

Rubber Gasket

Screws

Drain Elbow




### Single Snap Assembly Kit - 193800

Simple Snap Tool

Snap Ring

Replacement Power Cord Kit

1024



### Garbage Disposals

MODEL

EXL100c

### Other Available Accessories



#### Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

#### Air Switch Base Unit

Air Switch Remote Controller	ARC-4200
------------------------------	----------

#### Additional Air Switch Button Finish Options:

Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Mediterranean Bronze	AS-4201-BRB
Polished Brass	AS-4201-BR
White	AS-4201-WH
Almond	AS-4201-AL
Biscuit	AS-4201-BIS

#### Optional:


Dishwasher Connector Kit

1023



Unjamming Wrench

1037



Light Collar Replacement

195182

