MOEN®

ILLUSTRATED PARTS

Garbage Disposals

MODELS EX50C
EX100C

■ **Order by Part Number**

Stopper - Polished Stainless
1011



Removable SplashGuard
205497



Sink Flange
193900



Mounting Assembly Kit - 1824

Fiber Gasket



Backup Flange



Screws (x3)



Mounting Ring


Snap Ring



Cushion Mount



Lower Mounting Ring




Drain Elbow Kit - 1026

Rubber Gasket

Screws

Drain Elbow




Simple Snap Assembly Kit - 193800

Simple Snap Tool



Snap Ring





Replacement Power Cord Kit
1024

Other Available Accessories



Air Switch Remote Controller

- Installs into existing sink hole (ranging from 1-1/4" to 1-3/8") to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.


Air Switch Base Unit	
Air Switch Remote Controller	ARC-4200
Additional Air Switch Button Finish Options:	
Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Mediterranean Bronze	AS-4201-BRB
Matte Black	AS-4201-BL
Brushed Gold	AS-4201-BG
Polished Nickel	AS-4201-NL
Black Stainless	AS-4201-BLS
Spot Resistant Stainless	AS-4201-SRS

Optional:

Dishwasher Connector Kit
1023



Unjamming Wrench
1037



TO ORDER PARTS CALL: 1-800-BUY-MOEN
www.moen.com